







Handpiece Maintenance Guide: Highspeed Handpieces

*** Maintenance procedure after every patient ***

Post This In Your Sterilization Room

Post This In Your Sterilization Room

 <p>Step 1</p>	 <p>Step 3</p>	 <p>Step 4</p>	 <p>Step 5</p>	 <p>Step 6</p>	 <p>Step 7</p>
<p>Wipe down the handpiece with a damp disposable cloth to remove all debris.</p> <p>Do not use any chemical solutions for cleaning, do not submerge the handpiece in water / ultra sonic cleaner, or disinfectant</p>	<p>Connect the nozzle adapter to the back end of the handpiece. Spray lubricant into handpiece for approximately 3 seconds. Count 1...2...3</p> <p>Rotate bur back and forth between your fingers to further distribute the lubricant in the head of the handpiece and help loosen debris in that area.</p>	<p>Connect handpiece to an air supply.</p> <p><i>We recommend use of the DCI HP Flush Station and not the chair-side air line to prevent clogging, cross contamination and discoloration in your air line.</i></p> <p>Before you apply air pressure; position the head of the handpiece within a paper towel.</p> <p>Run the handpiece for approximately 10 seconds.</p> <p>If the purged lubricant on the paper towel is not clear, re-lubricate and purge until the fluid in completely clear. Continue to run the handpiece until all excess lubricant is expelled.</p>	<p>Remove bur and lubricate the chuck using the "Spindle" adapter on your can of lubricant or use a pen droplet oiler.</p> <p>Using an interproximal brush clean out the chuck.</p> <p><i>Tip: If the handpiece is a push button autochuck : Push the headcap to fully open the chuck, with the chuck held fully open, insert the bur in and out repeatedly to enact a plunging action. This will loosen any debris in the chuck.</i></p>	<p>Clean the fiber optic glass (if the handpiece contains fiber optics) with a cotton swab and isopropyl alcohol. Be sure to clean the area on the back end and head.</p> <p>Water ports may be cleaned when needed with a cleaning tool.</p>	<p>Wipe down the exterior of the handpiece with a dry towel to remove any expelled fluid or debris. The handpiece should be completely dry at this point.</p> <p>Bag and sterilize according to the manufacturer's instructions.</p> <p>-Always allow handpiece to complete the drying cycle.</p> <p>-Do not sterilize with a bur</p> <p>-Do not exceed 275° F installed.</p> <p>-Do not relubricate handpiece after sterilization.</p>
<p>Step 2</p> <p>Choose the appropriate adapter for the back end of your handpiece (see list below) and thread the adapter to the lubricant nozzle (<i>i Spray recommended</i>)</p> <p>Insert bur into handpiece.</p>					

CAUTION:

Do Not Use chemical disinfectants, abrasive cleaners, antibacterial soaps as a cleaner.
Do Not Submerge into liquids

Do Not Use ultrasonic cleaners
Do Not Operate or run a handpiece without a bur correctly installed
Do Not Exceed 275° F (135°C) when autoclaving

Still have questions?

Give us a call, we would love to help you out!

800-221-0750
www.medidenta.com

3325 W. Ali Baba Lane - Suite 603
 Las Vegas, NV 89118



Your Direct Source for Endo and Handpiece Solutions